

Parker Tracking System

How To Add Serialization To Orders

Fast. Easy. Accurate.

Release 1.17 | Version 2 Parker Hannifin Corporation Copyright © 2017 Parker Hannifin Corporation



Table of Contents

How to Add Serialization to an Order	2
1: Navigation	. 2
2: Order Search	. 2
Enter Serial Number(s)	. 3
Enter QC Code(s)	. 4
Print	5

Darker ENGINEERING YOUR SUCCESS.

How to Add Serialization to an Order

A The serialization process is only available for dynamic assets (non-hose only). If you want this feature added to your account, please contact the PTS team.

1: Navigation

Click '**Order Search**' from PTS Essential in the navigation toolbar.



2: Order Search

Select an Order from Order Search and expand the 'Serial By Line' details.

ORDER SEARCH

Order Search: SUPERTEST-001 🔻 🗟 😂 🖨					
Sort By: Order Number					
Order Date					
⊠ Customer Info					
Serial By Line					
⊠ Attachments					
Iine/Seq: 001 / 001	1/2"-100R5-1750 PSI	5	(0)		8==
⊠ Line/Seq: 002 / 001		3	(0)		8 <u>-</u>
🗵 Line/Seq: 003 / 001	20-F-S-JIC 37-STR	3	(0)		8
⊠ Line/Seq: 004 / 001		3	(0)	٢	8= -
⊠ Line/Seq: 005 / 001	FILTER ASSEMBLY ORG FLT	1	(0)	۵	0



Enter Serial Number(s)

Enter a product "serial number" (or equivalent) for the order line(s). There will be a serial number box per part number on the line item.

ORDER SEARCH

Sort By: Order Number	
Order Date	
S Customer Info	
Serial By Line	
Line: 001	
Serial 1 Serial 2 Serial 3	
Serial 4 Serial 5	
Line: 002	
Serial 1 Serial 2 Serial 3	
Lines 002	
Emili Serial Serial Serial 2	
Senal 1 Senal 2 Senal 3	
Line: 004	
Serial 1 Serial 2 Serial 3	
Line: 005 Serial 1	



Enter QC Code(s)

When you load component parts, you can also add quality information in '**QC Code**' available on the Line item(s).

ORDER SEARCH

Order Sea	rch: SUPERTE	ST-0	01 🔻 🌡) 2 (
Sort By:	Order N	umbe	r							
	Order Date	ate								
Custom	ner Info									
🖄 Serial	By Line									
🗵 Attachr	ments									
A Line/Seq	: 001 / 001					1/2"-100R5-1750 PSI	5	(0)		0
Part Number	Part Desc	QPA	Length	UOM	QC Code					
201-10	1/2"-100R5-1750 PSI	1	0	in						
10126-8-10	26-M-R-NPTF- STR	2	0	PC						
Part Number	Part Desc	QPA	Length	UOM	QC Code					
201-10	1/2"-100R5-1750 PSI	1	0	in						
10126-8-10	26-M-R-NPTF- STR	2	0	PC						
Part Number	Part Desc	QPA	Length	UOM	QC Code					
201-10	1/2"-100R5-1750 PSI	1	0	in						
10126-8-10	26-M-R-NPTF- STR	2	0	PC						
Part Number	Part Desc	QPA	Length	UOM	QC Code					
201-10	1/2"-100R5-1750 PSI	1	0	in						
10126-8-10	26-M-R-NPTF- STR	2	0	PC						
Part Number	Part Desc	QPA	Length	UOM	QC Code					
201-10	1/2"-100R5-1750 PSI	1	0	in						
10126-8-10	26-M-R-NPTF- STR	2	0	PC						
⊠ Line/Seq	: 002 / 001						3	(0)	٥	0= •-
⊠ Line/Seq	: 003 / 001					20-F-S-JIC 37-STR	3	(0)		8 <u>-</u>
⊠ Line/Seq	: 004 / 001						3	(0)	٥	0
⊠ Line/Seq	: 005 / 001					FILTER ASSEMBLY ORG FLT	1	(0)		8 <u>-</u>

Darker ENGINEERING YOUR SUCCESS.

Print

Once you enter the serial numbers, you can print them on the label using supported label formats, such as **GeneralLabel_ACD.lwl**.

1 The serial numbers and QC codes are saved within the PTS ID record after print.

Click the print icon to print the entire order:

ORDER SEARCH

Order Search: SUPERTEST-001 🔻 🗟 🔁 🖨					
Sort By: Order Number					
Order Date					
⊠ Customer Info					
Serial By Line					
🗵 Attachments					
Ime/Seq: 001 / 001	1/2"-100R5-1750 PSI	5	(0)		0 0 8
⊠ Line/Seq: 002 / 001		3	(0)	٥	8== ==
⊠ Line/Seq: 003 / 001	20-F-S-JIC 37-STR	3	(0)	۵	8
⊠ Line/Seq: 004 / 001		3	(0)	٥	0
⊠ Line/Seq: 005 / 001	FILTER ASSEMBLY ORG FLT	1	(0)	۵	9

Alternatively, you can print by line item:

Eine/Seq: 00	01 / 001					1/2"-100R5-1750 PSI	5	(0)		:=-
🗵 Line/Seq: 00	02 / 001						3	(0)	۵	8 <u>-</u>
Line/Seq: 00 Part Number Part Number Part Number	03 / 001 Part Desc Part Desc Part Desc	QPA QPA QPA	Length Length Length	UOM UOM UOM	QC Code QC Code QC Code	20-F-S-JIC 37-STR	3	(0)	P	int PT S
Eine/Seq: 00	04 / 001						3	(0)	٢	8==
🗵 Line/Seq: 00	05 / 001					FILTER ASSEMBLY ORG FLT	1	(0)		8== ==